

# BOOM STAND INSTRUCTION



## THE PARTS LIST

1. Base
2. Vertical post
3. Base tight screw
4. Saver ring
5. Cross block
6. Horizontal post
7. groove tight screw
8. Top cap
9. Tight screw

If missing any parts, please contact the manufacturer or local dealer.

**STEP 1** Open the Boom Stand box, checking the package contents.



**STEP 2** Use the Screw 3, to attach the Base 1 and the Vertical Post 2 together, and put it on the table.



**STEP 3** Put the Saver Ring 4 on the vertical post



**STEP 4** Put the Cross Block 5 on the vertical post and tight the right side tight screw.



**STEP 5** Put the Horizontal Post 6 in to the Cross Block, and tight the left side of tight screw. Please confirm the slot of the Horizontal post should on the top side, and use the screw 7 to fix the Horizontal post, when the horizontal post on the end of cross block, it can't be out.



**STEP 6** Put the tight screw 9 on the side of horizontal post.



**STEP 7** Put the Cap 8 on the top of the vertical post.



## SPECIFICATIONS

Weight: 39.57lbs, 17.95kg Size of base: 11.22 x 10.236 x 0.709" (285x260x18mm)

Maximal size from vertical post to the front of base: 9.38" (238.25mm)

Horizontal bar: 19" (483mm), Diameter: 1.465" (37.2mm)

Vertical post: 15.1" (384mm), Diameter: 1.465" (37.2mm).

The size can be up to 25" (634mm) if the extension post is attached.

Diameter of mounting holes in the front of horizontal bar: 5/8" (15.875mm). Maximal bearing load on the front of horizontal bar: 21lbs, 9.526kg

## ATTENTION

You may receive the different model of the Stands according your order, please check the bellow

Note: The stands of specifications are consistent with standard BoomStand.

Please take the same of instruction for the installation, if any questions, please call the manufacture or the local dealer.

### Clamp Stand

Maximal open size of clamp: 1.575"  
(40mm) Weight: 22.49lbs, 10.2kg



### U-Type Base Stand

Base Dimension(L x W x H): 450x360  
x30mm. Weight: 19.16lbs, 17.25kg



### Big Base Stand

Size of Base: 15.512x14.961x0.472"  
(394x380x12 mm) Weight: 40.67lbs,  
18.45kg



## BOOM STAND ACCESSORIES

We also supply the other accessories to fit your application (note: the items are not including in the boom stand package)

### 76mm / 83mm / 85mm E-Arm



### 39mm E-Arm



### Fine focus E-Arm



### B&L E-Arm



### CCD Mounting Plate



### CCD Mounting Plate with Focus



### 76mm Through Hole Focus Rack



### 32mm / 25mm Arbor



## HOW CAN ATTACHED THE STANDARD E-ARM

On the top



On the horizontal



On the bottom. Warring: please use the safety screw when you put the E-Arm on the bottom of the hole.



Howard Electronic Instruments, Inc. Address: 974 SE Pioneer Road. El Dorado, Kansas 67042

Tel: 1-800-394-1984 Fax: 316-321-2803 Website: [www.heiscope.com](http://www.heiscope.com) Email: [sales@heiscope.com](mailto:sales@heiscope.com)